



- 1) M6; depth 10 (4x)
- 2) \varnothing 6H7; depth 6 (4x)
- 3) counterbore for screw DIN 912 / ISO 4782 - M6 (4x) used from top-side
- 4) counterbore for screw DIN 912 / ISO 4782 - M6 (3x) used from top-side
- 5) \varnothing 6H7; depth 6 (2x)

*) positional accuracy between fits: \oplus 0.02

